




Alice1101983

Output DC 5V

Output Enable Key(Low pulse trigger)

Trigger once:turn on output

Continuous trigger twice:turn off the output



KEY

VOUT

GND

GND

BAT

GND

VIN

Battery level indicator

Input DC 4.5-5.5V

Charge and discharge interface 4.2V